



**NOTES:**

1. Teensy 3.2 (A3): Unlink USB VBUS from VIN (cut bridge, under-side) before fitting to main board.
2. Teensy 3.2 (A3): Connect pads 2-33, 9-30 and 10-29 before fitting to board (see photos).
3. DC/DC boost converter (A1): Input range must include  $1V < V_{in} < 3.2V$ . (Do not use VB9208.)

Design by M.J. Bauer  
 Originated: Nov. 2021

[www.mjbauer.biz](http://www.mjbauer.biz)

Sheet: /  
 File: REMI-3-main-board-A4.sch

**Title: REMI 3 - All-in-One EWI - main board**

Size: A4 Date: 2022-02-03  
 KiCad E.D.A. kicad (5.1.9)-1

**Rev: 1.1**  
 Id: 1/1